

SENARAI BERING ARAH KIBLAT BAGI DAERAH-DAERAH NEGERI SABAH

Bil	Nama Bandar/Pekan	Garis Lintang	Garis Bujur	Azimut Arah Kiblat	Sudut Convergence	Bering Arah Kiblat
		° ' "	° ' "	° ' "	° ' "	° ' "
1	KUDAT	06 53	116 50	290 24 31	-0 19 33	290 04 58
2	PITAS	06 45	117 03	290 26 50	-0 20 59	290 05 51
3	KOTA MARUDU	06 32	116 46	290 29 32	-0 19 23	290 10 09
4	KOTA BELUD	06 23	116 38	290 31 32	-0 18 41	290 12 51
5	KOTA KINABALU	05 59	116 04	290 36 55	-0 15 42	290 21 13
6	TUARAN	06 13	116 17	290 33 36	-0 16 45	290 16 51
7	BEAUFORT	05 22	115 44	290 46 07	-0 14 15	290 31 52
8	KUALA PENYU	05 35	115 35	290 42 49	-0 13 23	290 29 26
9	KENINGAU	05 20	116 10	290 46 36	-0 16 30	290 30 06
10	SIPITANG	05 05	115 33	290 50 27	-0 13 27	290 37 00
11	TAMBUNAN	05 42	116 23	290 41 18	-0 17 34	290 23 44
12	TENOM	05 08	115 56	290 49 35	-0 15 21	290 34 14
13	PENSIANGAN	04 33	116 20	290 57 51	-0 17 22	290 40 29
14	PAPAR	05 44	115 56	290 40 37	-0 15 07	290 25 30
15	RANAU	05 57	116 43	290 37 54	-0 19 22	290 18 32
16	BELURAN	05 53	117 33	290 39 37	-0 24 21	290 15 16
17	TELUPID	05 47	117 05	290 40 33	-0 21 33	290 19 00
18	KINABATANGAN	05 36	117 56	290 43 46	-0 26 41	290 17 05
19	SANDAKAN	05 51	118 07	290 40 43	-0 27 55	290 12 48
20	KUAMUT	05 14	117 29	290 48 18	-0 23 51	290 24 27
21	LAHAD DATU	05 01	118 20	290 51 30	-0 28 53	290 22 37
22	KUNAK	04 41	118 15	290 55 37	-0 28 06	290 27 31
23	TAWAU	04 16	117 53	291 00 51	-0 25 34	290 35 17
24	SEMPORNA	04 29	118 37	290 58 06	-0 30 10	290 27 56

Sumber: Jabatan Ukur dan Pemetaan Malaysia